

Lifetime
WARRANTY



NON-PRORATED LIMITED WARRANTY

Permalatt Products, Inc., warrants to the original purchaser only that Permalatt vinyl lattice and vinyl products, under normal use and service, (a) will not peel, flake, rust, blister, crack, corrode or become brittle, and (b) will not require painting, replacement or maintenance due to deterioration.

This Limited Warranty covers defects in material and workmanship arising during the manufacturing process.

If the purchaser is a living person and the lattice is purchased for personal or household application, the warranty period is the lifetime of the purchaser; in all other instances, the warranty period is 30 years from the date of purchase.

All claims under this Limited Warranty must be made in writing to Permalatt Products, Inc., P.O. Box 405, Bremen, IN 46506, within the warranty period and promptly after discovery of the claimed defect, describing the defect claimed, together with the proof of purchase. If a claim is made, Permalatt Products, Inc. shall have a reasonable time and opportunity to inspect the lattice. If the lattice has defects in material or workmanship covered by this Limited Warranty, and the warranty claim is made in accordance with the terms hereof, then Permalatt Products, Inc. shall, at its option, either replace the product or refund the original purchase price. Freight, labor and any other similar costs shall not be paid by Permalatt Products, Inc.

This Limited Warranty is void if any of the following occurs with respect to the product: (a) improper installation, (b) misuse, neglect, vandalism, accident or improper storage, (c) altering or changing the product by reason of applied heat, welding, solvent, epoxies or any other alteration, (d) impacts of objects, fire, flood, hurricane, tornado or other storms, or casualty or acts of war, (e) painting the surface of the product, or (f) adverse effects of air pollution.

This Limited Warranty contains the only express warranties made by Permalatt Products, Inc., and sets forth the purchaser's exclusive remedy for breach of warranty. No other warranties, express or implied, are made. Permalatt Products, Inc., specifically disclaims the implied warranties of merchantability and fitness for any particular purpose, and shall not be liable for any direct, special, incidental or consequential damages.

This Limited Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.



Permalatt Products, Inc.

Vinyl Lattice

Care and Cleaning Requirements

Permalatt Products, Inc.'s Vinyl products add beauty, distinction, and a lasting value to your home. Your homes exterior requires cleaning and Permalatt Products Vinyl Lattice is no different. Over time, with exposure to outdoor elements, your lattice will show signs of normal weathering such as a slight loss of gloss and a slight color change. Cleaning your Vinyl products is the best way to protect your investment by minimizing the effects of weathering as well as removing dirt, grime, and other substances detrimental to the appearance of your lattice.

Hand Washing Instructions

1. Wet the Permalatt Products, Inc. Vinyl lattice with a garden hose
2. Hand wash all surfaces with a sponge, soft cloth, or soft bristle brush using a mild detergent (see recommendations below)
3. For best results start at the top of the lattice and work downward
4. Thoroughly rinse the product to remove all residues. Water with a high solids or mineral content may leave spots – for areas with these issues we recommend drying the lattice with a soft white cloth.

Pressure Washing Instructions

1. A pressure washer can be used as a cleaning aid with or without a cleaning solution additive.
2. The pressure capabilities of pressure washers vary greatly. Test your pressure washer setting in a less visible area and inspect the results prior to completing the entire project. Wash all exposed surfaces
3. Rinse thoroughly, if detergent is added to pressure washer. In areas where water may have a high solids or mineral content we recommend drying with a soft white cloth to avoid spots.

Detergent Requirements

General purpose household soaps and detergents are acceptable. Do not use any type of soap or detergent that recommends gloves or respirators for personal protection. Do not use cleaners containing organic solvents, undiluted chlorine bleach, liquid grease remover, nail polish remover, furniture polish and cleaners, chlorinated hydrocarbons, ketones, and/or esters.

Lacquer thinner from your local hardware or paint store is also effective for small areas of stain or dirt. The lacquer thinner should never be applied directly to the vinyl. Apply lacquer thinner to a cotton cloth to make it moist and clean vinyl with moist cotton cloth. This should remove stains from oil based causes, such as tar. A Permalatt Products, Inc. Vinyl Maintenance Log (use attached schedule) is required to be maintained for all vinyl products. Disregarding this cleaning schedule will void the Permalatt Products, Inc. warranty.



PERMALATT PRODUCTS MAINTENANCE LOG

Installation Date: _____

Product Name(s): _____

Product Model(s): _____

Purchased From: _____

Date	Cleaned by Whom	Type of Cleaner(s) Used	Process
Example 1: 5/6/2017	Homeowner/Cleaning Service	Soap/Detergent	Hand Wash - Sponge

